


**ZAPOJENÍ CÍVEK
V KRYTECH**

Rozmístění cívek
odpovídá zapojení
pod chassis

- E20
20Y40
(PY83)
- E18
21L40
(PL81)
- E19
20Y4Q
(PY83)


PŘÍLOHA I.


R	32, 34, 29, 28, 33, 30, 35, 31, 36,	52, 55, 102, 101, 103, 54, 53,	122, 105, 108, 104, 106, 209, 125, 124, 121, 155, 161, 159, 153, 154, 156, 157, 227, 135, 158, 226	138, 230, 229, 145, 141, 109, 37,	172,	203, 204, 167, 201, 171, 202,	168, 166, 169, 206, 205
C	20, 26, 25, 24, 21, 23, 22,	27,	61, 60, 57, 58,	56, 59, 225, 139, 140, 123, 151, 164, 152, 162, 163, 132, 131, 134, 137, 136, 211, 212, 228, 133, 38, 221, 143, 213, 207,	231, 142, 144, 146, 208, 210, 214,	87, 74, 86, 84, 81, 80, 75, 72, 82, 85, 83, 78, 222, 224, 223, 79, 77, 76	
L	34, 30, 35, 41, 36,	37, 38, 39, 24, 51, 102, 53, 101, 54, 57,	123, 121, 151, 122, 204, 159, 160, 155, 158, 153, 154, 161, 156	42		170, 171, 201,	165, 166, 163, 169, 168, 167
	25, 33, 29, 27, 23, 32, 26, 59, 60, 66, 58, 63,	64, 65	135	133, 207, 134, 131, 132,	162, 136, 202, 137, 203	139, 138, 141, 206, 140, 143, 205,	142
		41, 25, 24	42			81, 82, 82, 83	87
						72, 71	79, 78, 77, 75, 74, 73, 76
							84, 85, 86




www.radiojournal.cz
ZAPOJENÍ TELEVISNÍHO PŘIJIMAČE 4202 A

R	2,3	5, 4, 5	7, 8	9, 10, 11	12, 13, 14	15, 16, 17, 18	19, 20, 21	22, 23, 24	25, 26, 27	28, 29, 30	31, 32, 33, 34	35, 36, 37	38, 39	40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51	52, 53, 54, 55	56, 57, 58	59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92			
C	221, 222, 2, 223, 1, 6	4, 5	P	8, 10, 11	14, 15, 16, 18, 19, 21, 22	23, 24, 3, 38, 25	26, 27, 28, 29, 30	32, 31, 35, 34	35, 37, 20, 41, 24, 42	24, 52, 53	57, 55, 54, 56, 58	60, 59, 61	62, 63	67, 65, 64, 65, 71, 72, 74	75, 77, 75	73, 73, 78, 75, 77	75			
L	9, 1, 1, 2	7, 84, 85, 85	6	81, 82, 82, 83, 3, 5, 4	8, 87	11, 12, 10'	25	43, 45, 47, 44	61, 62	45	49, 49, 49, 22	35, 21, 21, 20	52, 51, 41	37	30, 33, 53, 54	65	67, 64, 34, 35, 35, 35'	65, 67, 68, 69	42, 43	39, 40, 40', 41, 41', 42, 42'







6CC42




6F36




6B32




6CC41




UBL 21




21L40




6L43




UY1NS



20Y40



1Y32T



350QP44

ZAPOJENÍ PATIC POUŽITÝCH ELEKTRONEK

1J5		1,5 pF		0,1 W
100		100 pF		0,25 W
10k		10000 pF		0,5 W
1M		1 μF		1 W
G1		100 μF		2 W
10		10 pF		3 W
M1		0,1 MΩ		4 W
1M		1 MΩ		5 W