


R	1, 2,	9,	3, 8,	5,	6, 12, 11,	13,	7,	4,	14,	15,	16,	17,	16,
C	16, 25,	13, 27, 28, 29, 45,	17,	43, 26, 30, 48,	32,	20, 14, 31, 33, 34, 35,	19, 21,	44,	22,	42,	38, 37, 36,	23,	39, 24, 40,
L	40,	26, 27, 30, 32, 31, 33,		28, 29, 35, 34,	21, 22,			29, 24, 24,					47, 48,




UCH21 UY1N

UCH21

UBL21


PŘEPÍNAČ P1



ROZSAH	SPOLJENÉ DOTEKY P1
kV	2-3-4, 15-17
SV	4-5-6, 9-10-12, 17-18,
DV	20-21,

NAPĚTÍ	SPOLJ DOTEKY P2
120V	a-b, c-d, e-f,
220V	a-e, b-c,

PATICE ELEKTRONEK



Zapojení přijímačů 305U, 306U, 307U, 308U, „TALISMAN“