



R	3, 2, 25,	4, 19,	5,	1, 22,	8,	11, 7, 9, 27, 10, 18, 15,	22, 24, 16, 26, 13, 23, 12,
C	8, 16,	3, 4, 5, 17, X, 39, 1,	Y, 42,	19, 18, 2, 41,	6, 7, 10, 20, 9, 11, 23,	12,	25, 15, 29, 30, 26,
L	1, 2, 3, 4, 13, 23, 4,	31, 34, 32, 32, 33,	5, 6, 7, 12, 5, 6, 7,	8, 8', 9,	10, 11,	24, 14,	31, 36, 32, 40,
							14, 15, 16,



PATICE ELEKTRONEK



ROZSAHY	9-10, 11-2, 6-7, 8,	1-2, 7-8,
KV	9-10, 11-3, 7-8,	6-12, 11-3,
SV	9-10, 11-3, 7-8,	6-12, 11-3,
DV	9-10, 11-4,	11-4,
Ø	10-11, 11-5,	11-5,

POLOHY VOLIČE	9-12, 3-4,
ŘEČ	2-12, 3-5, 10-11,
ÚZKÉ PÁSMO	2-12, 3-6,
ŠIROKÉ PÁSMO	2-12, 3-7, 11-10,

PŘEPÍNAČE P1/P2/P3

